



Pearlizer DM-210

Pearlizer (珠光浆)

DM-210 is one kinds of pearl shine concentrate from Ethylene Glycol Distearate , Alkyl Ether Sulfates and Alkanolamides MEA. Under special process, DM-210 is unique and excellent. It can be used in shampoo, rinse, shower cream, facial cream, hand lotion and other liquid cleaning products for good appearance.

DM-210 是由乙二醇双硬脂酸酯、AES、CMEA 等配制，采用独特工艺配方生产的优质珠光浆，可赋予香波、沐浴露、洗面奶、洗手液等液洗产品美丽的珠光。

Characters (特点)

Low Viscosity	粘度低，流动性好
Easily dispersed	分散速度快，易于操作
Crystalloid grain symmetry, good opacity, silky feeling	晶体粒径均匀，遮光性好，丝稠般质感
Good thermotolerant	热稳定性能好

Specification (规格)

Test Item	Specification	Analytical Method
Appearance	White Pearl Liquid	-----
pH 值 (10%水溶液) pH	6.0~8.0	GB/T 6368
粘度 (25℃) Viscosity	<10000cps	GB/T 15357
活性物含量 Active Substance	27.0±2.0%	GB/T 13173
铁含量 Iron	≤0.0002%	GB/T 3049
砷含量 Arsenic	≤0.0003%	GB/T 7917
重金属 (以 Pb 计) Heavy Metals	≤0.0015%	GB/T 7917
菌落总数 Total count	≤500/g	GB/T 7918
霉菌及酵母菌 Yeasts & Moulds	≤500/g	GB/T 7918

Handling (使用方法)

- 1、Added DM-210 in the system amount 40-45℃ and mixed.
体系降温到 40-45℃，加入 DM-210，充分混合。
- 2、Don't add DM-210 over 50℃. 使用温度不得超过 50℃。
- 3、Usage concentration of 3.0 to 5.0%(by weight). 推荐用量为 3.0~5.0% (重量份)。

Packing: (包装) 150kg.net in Plastic Drum .塑料桶，净重 150 公斤。