



Pearlizer DM-2000

Pearlizer (珠光浆)

DM-2000 is one kinds of pearl shine concentrate from Ethylene Glycol Distearate, Alkyl Ether Sulfates and Alkanolamides MEA. Under special process, DM-2000 is unique and excellent. It can be used in shampoo, rinse, shower cream, facial cream, hand lotion and other liquid cleaning products for good appearance.

DM-2000 是由乙二醇双硬脂酸酯、AES、CMEA 等配制，采用独特工艺配方生产的优质珠光浆，可赋予香波、沐浴露、洗面奶、洗手液等液洗产品美丽的珠光。

Characters (特点)

Low Viscosity	粘度低，流动性好
Easily dispersed	分散速度快，易于操作
Crystalloid grain symmetry, good opacity, silky feeling	晶体粒径均匀，遮光性好，丝稠般质感
Good thermotolerant	热稳定性能好

Specification (规格)

Test Item	Specification	Analytical Method
外观 Appearance	有珠光的白色膏体 White Pearl Liquid	-----
pH 值 (2%水溶液) pH	6.0~8.0	GB/T 6368
粘度 (25℃) Viscosity	≤10000cps	GB/T 15357
活性物含量 Active Substance	40.0±2.0%	GB/T 13173.2
菌落总数 Total count	≤10cfu/g	GB/T 7918.1
霉菌及酵母菌 Yeasts & Moulds	≤10cfu/g	GB/T 7918.1

Handling (使用方法)

- 1、Added DM-2000 in the system amount 40-45℃ and mixed.
体系降温到 40-45℃，加入 DM-2000，充分混合。
- 2、Don't add DM-2000 over 50℃. 使用温度不得超过 50℃。
- 3、Usage concentration of 3.0 to 5.0%(by weight). 推荐用量为 3.0~5.0% (重量份)。

Packing: (包装)

150kg net in Plastic Drum . 150kg/桶。